



Top-End Assembly, 2

Set up feet (parts 7-001) on lower top-end fixture (drawing AST-11-A03). Align the four legs (parts 7-002 with 7-003 attached) as shown, using upper top-end jig (drawing AST-11-A05). Maintaining the separations specified between the strut attachment holes may require making straps of the right length to bolt into the holes.

|                      |            |
|----------------------|------------|
| Tenn. State Univ.    |            |
| CASS 2-m AST Project |            |
| 02/05/97             | AST-07-R02 |
| J.A.E.               |            |